



Chromebook Tips

If your device runs slow, fails to load pages, struggles to navigate websites, does not power on, or is just not working as well as it could, here are some tips to get your device, and YOU, ready for learning:



1. **Updating** your Chromebook. **Updates** contain important changes to improve the performance, stability, and security of the applications that run on your computer (*recommend monthly*):

- Go into settings by clicking the three dots on the top right
- Select “help”
- Select “about Chrome” to look for an update

2. Clearing the **cache/data** from your device. Too much information saved in your **cache** will cause browsing the web to be slow. Deleting the **cache/data** helps to troubleshoot, increases the loading time of web pages, and increases the performance of your computer (*recommend twice a month*):

- Go into settings by clicking the three dots on the top right
- Search & click on “cache”
- Choose “all time” from dropdown menu
- Click on “clear”

3. Removing **Profiles**. Every time someone logs on to your Chromebook, it will save the profile, and multiple profiles slow your device (*recommend as needed*):

- Go to sign-on screen to see all the profiles saved to your Chromebook
- Click on the drop down arrow beside each name then choose “remove account”
- Do this for each random name you see, including your own profile